


## INSTRUCTIONS FOR MAILCARRIER


### TO DEPOSIT PACKAGES

1



UNHOOK SACK AND DEPOSIT  
PACKAGES

2



CLOSE SACK BY THREADING  
EYELETS ONTO BRACKET.  
ALTERNATE EYELETS FROM  
TWO SIDES AS SHOWN TILL  
SACK IS CLOSED.

3



SECURE CROSS-LINK ONTO  
BRACKET. THREAD ATTACHED  
PADLOCK THROUGH HOLE IN  
BRACKET AND LOCK PADLOCK.

### TO DEPOSIT/RETRIEVE MESSAGES



DEPOSIT MESSAGES IN THE  
TRANSPARENT POCKET.  
PICK UP DELIVERY NOTICES OR  
AUTHORIZATION SLIPS FROM  
POCKET


Thank you for buying the Package Park™ package receiving system. The Package-Park™ package delivery system allows you to receive packages when you are not in. You can –

- . Receive packages from private carriers and couriers.
- . Receive magazines, newspapers and bulky mail items.
- . Insure your privacy.
- . Protect your packages from theft.
- . Protect your packages from rain.
- . Receive packages from friends.
- . Use it to “hold” articles for friends to pick up.


The receptacle allows you to receive packages at home, hold or dispense articles at home without your having to be there. It is ideal for catalog and TV shoppers, Home businesses, and anyone who receives mail at home.

The Package-Park™ was developed for your convenience. Please take a few minutes to read the following instructions. They will show you how to obtain the most from your product.

The Package-Park™ bracket was designed for use on doors which swing inwardly into a room. The bracket is designed to resist unauthorized removal when used with this kind of door. The front doors of apartments and single family homes are usually inwardly swinging. The front doors of apartment complexes, office buildings and public buildings are usually outwardly swinging. Please do not use the package park on outwardly swinging doors.




Read the instructions on the 6"x 9" card. These instructions show the mailcarrier how to deposit packages in your Package-Park™ sack.




Place the 6"x 9" card inside the transparent pocket of the sack as shown. The instructions should be clearly visible in the pocket.

THE PACKAGE-PARK™ SACK IS NOW FULLY ASSEMBLED. IT IS NOW READY FOR USE.

#### DEPLOYING AND USING THE PACKAGE-PARK™ RECEPTACLE



Open the front door to your apartment or home and place the bracket on the top of the door as shown. Close the door gently and ensure that the bracket does not prevent the door from closing. You may move the bracket along the top of the door till you find a portion where the door closes easily. If no suitable place is found, you may use the alternative position shown on the next page. The sack must rest on the floor in this case. Extra care must be taken to keep the sack out of rain. Rain damage may occur with the sack on the floor.




Alternative sack position

(Use this position if door is more than 7 ft high or if package weighs more than 20 lbs.)

Thread the eyelets of the sack unto the bracket using the sequence described on the 6"x 9" card for the mailcarrier. Secure the cross-link on the bracket and thread your padlock through the hole at the end of the bracket. Do not lock the padlock.

You must lock the door before leaving. This will prevent unauthorized entry and removal of the sack. The Package-Park™ sack is now ready to receive packages. Leave any note or authorization slip in the pocket of the sack so that it is visible.



When the mail carrier arrives he will remove any authorization slip from the pocket, deposit your package(s) and lock the sack with the padlock. He may leave messages for you in the pocket.

Deploy the Package-Park™ receptacle when:

1. You are expecting a package delivery.
2. You have received a delivery notice from a mailcarrier and another delivery attempt is expected.

### IMPORTANT


Your mailcarrier may not deliver some packages without written authorization from you. This is normally done using the delivery notice that is left behind. Write on the notice that you will like your package delivered in the Package-Park™ sack on your door. For example you may write:

Please deliver my package in the Package-Park™ sack on my door".  
(Your sack may come with a printed notice for this purpose)

Sign and date the notice.

If you are expecting a delivery by a private carrier, put the notice in the pocket of the sack so that it is showing when the mailcarrier arrives.

If you wish, you may write your own note and leave it in the pocket of the sack before the first delivery attempt is made. This will ensure the fastest delivery to you. Put all notices in the pocket, and behind the 6" x 9" card with the notice sticking up above the card. This will ensure that the notice is visible and does not obscure the instructions. This is illustrated in the following figure.



Leave authorization slips or notes behind and above the instruction card.

Note that the mailcarriers must have access to your door to deliver your package. If the main door to your apartment complex is locked, they will not be able to reach your door. DO NOT HANG PACKAGE-PARK™ FROM THE MAIN DOOR TO YOUR APARTMENT COMPLEX.

After you receive a package, you will need the key to the padlock to retrieve the package. Also unlock your door and remove the sack from the door. Avoid opening and closing your door frequently when the bracket is hanging on the door.

Please observe the following precautions.

#### IMPORTANT SAFEGUARDS

1. The bracket has been plastic coated to protect your door from damage. Do not use the product if it will not permit your door to close, or if it will damage your door.
2. Do not place cash, valuables, or other valuable materials in the sack. Do not attempt to use the receptacle for COD deliveries.
3. The sack is not tamper-proof. Do not use the product to receive important items or documents. Do not use the product if you will be away for extended periods.
4. The sack is not waterproof. Avoid placing it where it may be rained on.
5. Do not use the sack to receive explosives, or illegal materials.
6. Avoid bringing the sack near flames or hot objects. Placing it near heaters or vents could cause a fire hazard.
7. Keep the sack away from young children.
8. The presence of the sack on your door may be an indication that you're away. Do not use the product if security could be a problem.
9. Do not use the product on glass doors.
10. If your door has a section made of glass, do not deploy the product at or near that section to avoid damage to the glass.